


HYDRAULICS



REM2

**Setup and Programming Instructions
For the 2 Channel Receiver**



Features

- Wide Supply Voltage, 11.0 to 28.0 Volts AC/DC
- Two relay outputs. All outputs can be operated simultaneously
- Low current consumption
- Over 4 billion code combinations
- Crystal controlled for high reliability
- Can store unlimited number of transmitters
- Uses micro-controller technology that can be re-programmed to suit unique applications
- Momentary, Latching and Security Latching modes are all user selectable

Description

This Gigalink™ receiver gives you two relay outputs that can switch currents up to 8 Amps each. There is an onboard LED to indicate when the relay is “on”. The receiver has a power “on” LED to indicate that the correct supply voltage is connected. The receiver’s micro-controller can store unlimited number of transmitters with a high security level using the encrypted 32-bit digital code. Included with the receiver is the Gigalink™ programming cable.

Technical Data

Supply Voltage	11.0 to 28.0 Volts AC/DC.
Operating Frequencies	433.920 (Standard), 433.664, 433.408, 433.152MHz
Output	Relays, rated at 8 Amps / 240V
Recommended Antenna	ANT433 series (433MHz Series)
Compatible Transmitters	GLT433 MHz



Receiver Setup Instructions

The transmitter and receiver can be multi or single channel programmed.

Multi-channel Programming


This is used to program all channels from a multi-channel receiver to a multi-channel transmitter. Multi-channel programming can be achieved by following the steps below:

Step 1:	Connect power to the GIGALINK™ receiver. Make sure all switches on the mode dipswitch are off.
Step 2:	Momentarily short the two CC pins on the receiver board. This sets all the channels to a random code. If there are transmitters previously programmed, they will have to be re-programmed when CC pins are shorted. Do not do this step if you want to keep previously programmed transmitters.
Step 3:	Connect the multi channel transmitter to the multi-channel receiver by inserting the GIGALINK™ cable into the transmitters and receivers 2.5-mm Coding socket. (This will activate the programming mode and is indicated by the red light (LED), on the transmitter that must remain “on”).
Step 4:	Activate any two channels simultaneously on the multi-channel transmitter for one second, LED should blink twice to confirm code programming and then switch “off”.
Step 5:	Disconnect GIGALINK™ cable.

Repeat steps 3 to 5 to program another multi-channel transmitter.


If you are programming another transmitter, do not short out the CC pins. Shorting out the CC pins will delete all previously programmed transmitters.

**IF RECEIVER DOES NOT
RESPOND TO TRANSMITTER
YOU MAY NEED TO RECODE**




STEP 1

**TO DO THIS YOU WILL NEED
RED CODING WIRE**




STEP 2

**TEMPORARILY SHORT
CIRCUIT "CC" TERMINALS
WHICH RESETS RECEIVER**



STEP 3

**CONNECT CABLE TO
RECEIVER SOCKET**



STEP 4

**CONNECT OTHER END TO
TRANSMITTER, RED LIGHT
WILL ILLUMINATE, PUSH
TOP TWO BUTTONS UNTIL
RED LIGHT GOES OFF.
DISCONNECT AND USE.**



Single Channel Programming

This is used for programming one channel at a time to the transmitter. Single channel programming can be achieved by following the steps below:

- Step 1:** Connect power to the GIGALINK™ receiver. Make sure all switches on the mode dipswitch are off.
- Step 2:** Momentarily short the two CC pins on the receiver board. This sets all the channels to a random code. If there are transmitters previously programmed, they will have to be re-programmed when CC pins are shorted. Do not do this step if you want to keep previously programmed transmitters.
- Step 3:** Select the receiver channel, to be programmed, by setting the 2-way dipswitch. See dipswitch table below.

Dipswitch Setting		Receiver Channel
1	2	
Off	Off	1
On	Off	2

- Step 4:** Connect the transmitter to the receiver by inserting the GIGALINK™ cable into the transmitters and receivers 2.5-mm Coding socket. (This will activate the programming mode and is indicated by the red light (LED) on the transmitter that must remain “on”).
- Step 5:** **Activate one of the selected channels** on the transmitter for approximately one second, LED should blink twice to confirm code programming and then switch “off”.
- Step 6:** Disconnect GIGALINK™ cable.

Repeat steps 3 to 6 to program another transmitter channel.

If you are programming another transmitter, do not short out the CC pins. Shorting out the CC pins will delete all previously programmed transmitters.



Forward Programming

GIGALINK™ receivers have an additional programming feature, known as forward programming. This feature allows the user to program the transmitter code into the receivers. This will enable the transmitters to activate unlimited number of receivers simultaneously.

Forward Programming Steps:	
Step 1:	Connect power to the receiver and transmitter.
Step 2:	Place a jumper across the CC pins of the receiver.
Step 3:	Connect the transmitter and receiver using the coding cable.
Step 4:	Press the transmitter button for 2 seconds.
Step 5:	Remove the coding cable.
Step 6:	Remove the jumper from the CC pin.

The receiver is now programmed with the transmitter's code. Repeat the above steps to program another receiver.

Different Modes for the Output

Modes are user selectable from the 2-way dipswitch. Dipswitch 1 corresponds to output channel 1 and dipswitch 2 corresponds to output channel 2.

Momentary Mode	If the dipswitch is "off" the output will be in the momentary mode.
Latching Mode	If the dipswitch is "on" the output will be in latching mode.
Security Latching Mode	If security latching is required (Relay stays on until power is removed) the latching link should be inserted and soldered into the two holes to the right of the 2-way dip switch. This will enable the corresponding outputs to security latching.



Troubleshooting

This section contains helpful troubleshooting tips and solution.

Symptom	Solution
Receiver not responding to transmitter after programming.	Try to program the transmitter again, but this time with the battery connected to the transmitter. Check if GIGALINK™ cable is inserted correctly.
Transmitter activates wrong channel on a multi-channel receiver.	Wrong dipswitch setting while programming the receiver. Use the dipswitch table and program again.
Transmitter has short range.	Check receiver antenna connection. If you are using a shielded coax cable, check that the shield is connected to the negative and the coaxial core to the antenna terminal.
LED is flashing on the transmitter.	Replace battery.



Notes

[illegible]




Notes

This image shows a single sheet of white paper with horizontal blue ruling lines. The lines are evenly spaced and run across the width of the page. There are no margins, text, or other markings on the paper.



Notes

[illegible]



HYDRAULICS

VICTORIA

P.O. Box 1345
CLAYTON SOUTH. VIC. 3169
7 TREFOREST DRIVE,
CLAYTON VIC. 3168
Phone (03) 9544 5155
Fax (03) 9544 2511

QUEENSLAND

P.O. Box 5083
22 PINACLE STREET
BRENDALE QLD. 4500
Phone (07) 3205 3655
Fax (07) 3881 1592

NEW SOUTH WALES

47 SAMMUT STREET
SMITHFIELD, N.S.W. 2164
Phone (02) 9757 3866
Fax (02) 9575 3877

SOUTH AUSTRALIA

1/1 LINDFIELD AVENUE
EDWARDSTOWN, S.A. 5039
Phone (08) 8371 3822
Fax (08) 8371 3844

WESTERN AUSTRALIA

6 MELIADOR WAY
MIDVALE W.A. 6056
Phone (08) 9250 8155
Fax (08) 9250 8166

NEW ZEALAND

AUCKLAND
6/23 SPRINGS ROAD
EAST TAMAKI, 2013
Phone +64 9273 5470
Fax +64 9273 5471



www.crosshydraulics.com.au